



QUICK REFERENCE

FOR RECONSTITUTION

Step 1 – Press the “Start” button.

Step 2 – Key in the volume of water desired.

Step 3 – Press “Enter” on the keypad .

Step 4 – Confirm that the volume displayed on the screen is correct by pressing “Dispense H2O”.
The reconstitution process will begin.

Step 5 – Any volume dispensed above 30 mL will pause half way through for the user to shake the medication.

Step 6 – After reconstitution is complete, the Fillmaster unit will time out and the screen will shut off until next use.

ADDITIONAL FUNCTIONS

To calibrate the machine, press the “Program” button 4 times. The default setting for calibration is 5. You may adjust this setting by entering a higher or lower value. Be sure to have a graduated cylinder for precise calibration.

When the battery pack drops below $\frac{1}{4}$ power, it will display a “Low Power Warning” during every use. The user must call 619-596-9900 to order a new battery.